

# 智能移动数据终端



## 终端设备



**电源键**  
短按：点亮屏幕，锁定屏幕  
长按：关机状态下，长按3-5秒开机；  
开机状态下，长按3-5秒选择关机或重启。  
死机状态下，长按11秒，自动重启。

**扫描键**  
在应用打开时，按SCAN键可直接扫描

**音量键**  
调节音量大小

**返回键**  
点击返回键之前屏幕

**主页键**  
点击可快速回到主屏幕

**菜单键**  
点击可查看后台运行的程序，选择可关闭此应用

**自定义键**  
可自定义该键快捷功能



## SIM卡/TF卡



## SIM Card/TF Card



## 扫码功能

- 请在程序列表中找到扫描图标（图一），并点开。
- 在“扫描测试”界面中（图二），把扫描视窗对准条码，按扫描键进行扫描。
- 图三为扫描模块功能设置，首次出厂使用，需执行“恢复出厂设置”选项。



## NFC读卡功能

- 如果您的设备配有NFC读卡功能，请按以下指示操作：
- 请在程序列表中找到NFC图标（图一），并打开。
  - 在图二的读卡界面，将卡片靠近设备NFC感应区即可读卡。



## Barcode scanning

- If your device is equipped with barcode scanning, please follow the instructions below:
- Find the Scan icon in the list of programs, and open it. (Figure1)
  - The scanning window toward the barcode, press the Scan button to scan. (Figure2)
  - In the upper left corner click into barcode modules or Qr modules advanced settings. (Figure3)



## NFC read-write function

- If your device is equipped with NFC read-write function, please follow the instructions below:
- Find the NFC icon in the list of programs, and open it. (Figure1)
  - Put the card close to the NFC sensor area. (Figure2)



## 常见问题处理

- 设备不开机**
  - 按下电源键3-5s的时候设备屏幕才开始显示，请您在按电源键开机时等待屏幕有显示内容时再松开电源键。
  - 检查电池是否有电，请给电池充电。
  - 电池安装不正确，请重新正确安装电池。
- 设备跟电脑无法联机**
  - 如果设备插入电脑的USB接口后，没有任何提示，请您更换一个USB接口再测试一下，如还是没有任何响应，请更换电脑再测试。
  - 端口配置不对，机器“USB调试端口”未选中，请重新插线连接选择USB调试端口模式。
- 开机后黑屏**
  - 机器处于休眠状态，按电源键唤醒显示屏，一段时间不活动后，机器就会自动休眠。用户可自行设置休眠时间。
  - 电池没电，请给设备充电。
- 系统提示内存已满**
  - 机器存储太多文件，请删除一些文件或加大存储容量。
  - 系统安装太多应用，请删除一些不用的应用。
- 无法读取条码**
  - 未安装条码应用程序，在机器中加载扫描应用程序。
  - 条码不可读，确保条码无缺陷，并使条码在有效的读卡距离之内。
- 找不到蓝牙设备**
  - 与其它蓝牙设备距离太远，将设备移近其它蓝牙设备，相距10米以内。
  - 未开启附近的蓝牙设备，未开启附近的蓝牙设备，并选项蓝牙处于可发现模式。

## 注意事项

- 安全警告**
- 请将交流电插头插入与配件电源适配器上标识输入相对应的交流电插中；
  - 严禁在存有潜在爆炸气体的场所使用；
  - 非专业人员不要随意拆开主机以免发生危险；
  - 此为A级产品，在生活环境中，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对干扰采取切实可行的措施。
  - 关于电池的更换：
    - 用错误型号电池更换会有爆炸危险！
    - 更换后的旧电池应交维修人员处置，切勿把它投入火中！
- 重要安全说明**
- 避免在雷电期间安装或使用，否则有被雷电电击的危险；
  - 充电期间，当您发现有异常气味、过热或烟雾情形下，请立刻切断电源；
  - 请勿在无人看守的情况下充电，充满电后请及时拔除电源。
- 声明**
- 不在本指南说明的条件下使用和维护所造成的损坏；
  - 对于未经本公司同意进行拆机的，本公司将不承担任何责任；
- 免责声明**
- 由于产品更新，此文档的某些细节可能与产品不符，请以实物为准，此文档的解释权归本公司所有。保留不预先通知的情况下，修改说明书的权利。

## 包装内容

- 主机一台
- 用户指南一张
- 电源适配器一个
- USB数据线一个
- OTG数据线一根

## Notice

- Safety warning**
- Plug the AC adapter into the AC outlet relative to the identification on the adapter.
  - Prohibit to use in any potentially explosive gas places.
  - Non-professionals do not disassemble the device optionally to avoid danger.
  - This is a Class A product. In the daily environment, this product may cause radio interference. In this case, the user may be required to take effective measures for the interference.
  - With regard to battery replacement:
    - Replace with the wrong type of battery may cause explosion!
    - Please do not put the old battery into the fire!
- Important safety instructions**
- Avoid installation or use during the thunder and lightning in case electric shock by lightning.
  - When you notice abnormal smell, over heat or smoke. Please cut off the power immediately.
- Statement**
- if the use and maintenance of damage is not obeyed to this guide, the company will not assume any responsibility.
  - Without our consent disassemble, the Company will not assume any responsibility;
  - Due to natural disasters or man-made damage to the product, the company will not assume any responsibility.
- Disclaimer**
- Due to product updates, some of the details of this document may not match with the product, please in kind prevail. Interpretation of this document is owned by the Company. Reserve the right to modify specification without prior notice.

## Package

- 1\*Host
- 1\*User Manual
- 1\*Power Adapter
- 1\*USB Cable
- 1\*OTG Cable

# Intelligent mobile data terminal



## Terminal equipment



**Power**  
Short press: light up the screen, lock screen  
Long press:  
1. On off state, long press 3-5s to boot  
2. On boot state, long press 3-5s to shutdown or restart  
3. Under crash state, long press 11s to automatic restart

**Scan**  
When the application is open, press the SCAN button to scan directly

**Volume**  
Adjust the volume

**Return**  
Back to the previous screen

**Home**  
Rapid return to the main screen

**Menu**  
View the applications running in the background, choose to close the application

**Custom**  
Customizable shortcut function



## SIM Card/TF Card



## 使用指南

## User Manual